



## 1401-03

<b>OVERALL</b>	W96 D40 H32
<b>INSIDE</b>	W90 D24 H16
<b>SEAT HEIGHT</b>	17
<b>ARM HEIGHT</b>	26
<b>BACK RAIL HEIGHT</b>	32
<b>STANDARD WITH</b>	Welt on Outback & Arm Border Topstitching on Seat & Back Cushions All Down Back Cushions Cushion - naturalLEE
<b>SHOWN WITH</b>	Shown w/ Contrast Mini Flange in place of Topstitch