

# PALECEK®

601 PARR BOULEVARD | RICHMOND | CA 94801

## MOUNTING INSTRUCTIONS

### Reef Outdoor Wall Decor Large – White

107005




**These instructions are provided for your convenience. It is very important that they are read carefully and completely before beginning installation of this item.**

**Tools Needed:** Drill, Philip head screw bit, Measuring tape, Hammer, Bubble Level, and Pencil

### Parts List:

- A) Wall Decor x 1pc.
- B) 10"L Female Metal Cleat x 1pc.
- C) Wall Screw x 2pcs.
- D) Wall Anchor x 2pcs.



Side view of cleat engagement

### To Assemble:

1. Remove all parts and hardware from the box along with any plastic protective packaging. Do not discard contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
2. Place components on a non-scratching surface.
3. Determine the desired orientation of the Wall Decor. Decor is equipped with 1 Male Metal Cleat.
4. Using the appropriate size Female Metal Cleat, position cleat on wall in desired location and mark the hole locations on the wall with pencil.  
NOTE: It is strongly recommended to install cleat with screws attaching directly into wall studs.
5. Use bubble level to ensure level positioning.
6. Using the drill, pre-drill holes at marked locations.  
NOTE: If Wall Decor location will be installed in sheet rock or masonry, use appropriate drill bit size to accommodate wall anchors at locations between wall studs. Using a hammer, gently tap anchors into the holes until they are flush with the wall. Anchors provided are for sheetrock. For masonry anchors, consult your local hardware store.
7. Place Female Metal Cleat over hole locations and insert screws accordingly.
8. Tighten screws firmly. Do not overtighten.
9. Lift the Wall Decor, align the Male and Female Metal Cleats, then slide downwards firmly until cleats engage.
10. Installation is complete.

**Care Instructions:** Dust with a soft, dry cloth. Do not use abrasive cleaners