










ASSEMBLY INSTRUCTIONS

MODEL: #71857


Important note :

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
- Kindly follow the assembly instructions step by step.
- Do not tighten all screws and bolts until the chair is fully assembled.


PARTS LIST			
NO	DESCRIPTION	SRETCH	QTY
A	CHAIR BACK		1 Pc
B	CUSHION SEAT		1 Pc
C	FRONT LEG		2 Pcs

HARDWARE LIST			
NO	DESCRIPTION	SRETCH	QTY
1	BOLT (LONG)		4 Pcs
2	BOLT (MEDIUM)		4 Pcs
3	BOLT (SHORT)		1 Pc
4	SPRING WASHER		9 Pcs
5	FLAT WASHER		9 Pcs
6	ALLEN KEY		1 Pc

STEP 1



STEP 2



STEP 3

