


homestyles®

5523-681

Corner Cabinet




IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.


Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.


Part List




A.
Top
1 Pc.



B.
Fixed Shelf
1 Pc.




G.
Base
1 Pc.



H.
Shelf
4 Pcs.


Hardware List




Cam Lock Screw
42 pcs. (+2 extra)




Cam Lock
42 pcs. (+6 extra)



Magnet
4 pcs.



M3x13
Wood Screw
8 pcs. (+1 extra)



Adjustable Pin
16 pcs. (+1 extra)



M4x25
Machine Screw
4 pcs.



Knob
4 pcs.

For assembly see instructions in carton 5523-682.

homestyles Customer Service: www.homestylesfurniture.com,
servicedesk@homestylesfurniture.com, 888-680-7460