

ITEM: 5898-75210-85 Rectangle Dining Table

ITEM: 5898-75210-80 Rectangle Dining Table


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK

No	Drawing	Description	Size	Q'TY
A		Bolt	Ø5/16"*2-1/4"	8PCS
		Washer	Ø5/16"*19mm*1.5mm	
		Lock Washer	Ø5/16"*13*2mm	
B		Allen Key	12mm	1PC

Step 1:




ITEM: 5898-75210-85 Rectangle Dining Table

ITEM: 5898-75210-80 Rectangle Dining Table


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

Step 2: Push it tightly together and adjustable leveler.



Step 3: Pull both sides apart and flip the board over.




ITEM: 5898-75210-85 Rectangle Dining Table

ITEM: 5898-75210-80 Rectangle Dining Table

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

Complete



Adjust leveler if needed to level
case on uneven floor