HOOKER FURNISHINGS

ASSEMBLY INSTRUCTION


ITEM: 628-55110-89 Burleigh Entertainment Console

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Anti-Tip Kit		1 PC

PARTS LIST				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
1		Feet		6 PCS

Anti-tip kit is included for use. We recommend installing for safety reason.



Note: Anti-tip kit restraint is provided.
Please follow the instructions enclosed with the pack.


HOOKER FURNISHINGS

ASSEMBLY INSTRUCTION

ITEM: 628-55110-89 Burleigh Entertainment Console

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

Step 1:
Install the feet into the cabinet bottom by turning clockwise.




Note: Anti-tip kit restraint is provided.
Please follow the instructions enclosed with the pack.

HOOKER FURNISHINGS

ASSEMBLY INSTRUCTION

ITEM: 628-55110-89 Burleigh Entertainment Console

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



The adjustable shelf is screwed in place to avoid damage during transit. To adjust the shelf height, remove screws then place shelf pins in the desired level.

Adjust leveler if needed to level the console on uneven floor.

Note: Anti-tip kit restraint is provided.
Please follow the instructions enclosed with the pack.