HOOKER® FURNISHINGS

ASSEMBLY INSTRUCTION

ITEM: 6820-10415-80 Three Drawer Chest
6820-10415-85 Three Drawer Chest
6820-10415-99 Three Drawer Chest
6820-10417-80 Bookcase Hutch
6820-10417-85 Bookcase Hutch
6820-10417-99 Bookcase Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	69*27.2*4mm	1 PC
B		Mending Plate	100*25*2mm	2 PCS
C		Bolt	1/4"*20	4 PCS
D		Bolt	1/4*19mm	2 PCS
E		Lock Washer	1/4(6mm)	6 PCS
F		Flat Washer	1/4*16mm 1.5mm	6 PCS
G		Screw	8#*11/4	2 PCS
H		Plastic Anchor		2 PCS
I		Hanger	75*30*38mm 3mm	2 PCS
J		Connecting Plate	76*38*3mm	1 PC
K		Screw		2 PCS

PARTS LIST


NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
1		Bookcase Hutch		1 PC
2		Three Drawer Chest		1 PC

HOOKER® FURNISHINGS

ASSEMBLY INSTRUCTION

ITEM: 6820-10415-80 Three Drawer Chest
6820-10415-85 Three Drawer Chest
6820-10415-99 Three Drawer Chest
6820-10417-80 Bookcase Hutch
6820-10417-85 Bookcase Hutch
6820-10417-99 Bookcase Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



Assembly steps for connecting Three Drawer Chest (2) and Bookcase Hutch (1):


Place Bookcase Hutch (1) on top of Three Drawer Chest (2),
then secure them with mending plates (B), bolts (C), lock washers (E), flat washers (F) and a phillips screwdriver.

HOOKER® FURNISHINGS

ASSEMBLY INSTRUCTION

ITEM: 6820-10415-80 Three Drawer Chest
6820-10415-85 Three Drawer Chest
6820-10415-99 Three Drawer Chest
6820-10417-80 Bookcase Hutch
6820-10417-85 Bookcase Hutch
6820-10417-99 Bookcase Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



If assembling multiple bookcase hutches, secure them together using Connecting plate (J) and Screw (K), then tighten with a Phillips screwdriver.


The adjustable shelves are screwed in place to avoid damage during transit.
To adjust the shelf height, remove screws then place shelf pins in the desired level.

HOOKER® FURNISHINGS

ASSEMBLY INSTRUCTION

ITEM: 6820-10415-80 Three Drawer Chest
6820-10415-85 Three Drawer Chest
6820-10415-99 Three Drawer Chest
6820-10417-80 Bookcase Hutch
6820-10417-85 Bookcase Hutch
6820-10417-99 Bookcase Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



Adjust leveler if needed to level chest on uneven floor.