HOOKER® FURNISHINGS

ASSEMBLY INSTRUCTION

ITEM: 6820-10072-80 50in Desktop
6820-10072-85 50in Desktop
6820-10072-99 50in Desktop
6820-10413-80 Open Shelf Cabinet
6820-10413-85 Open Shelf Cabinet
6820-10413-99 Open Shelf Cabinet
6820-10417-80 Bookcase Hutch
6820-10417-85 Bookcase Hutch
6820-10417-99 Bookcase Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	69*27.2*4mm	1 PC
B		Mending Plate	100*25*2mm	2 PCS
C		Bolt	1/4"*20	4 PCS
D		Bolt	1/4*19mm	2 PCS
E		Lock Washer	1/4(6mm)	6 PCS
F		Flat Washer	1/4*16mm 1.5mm	6 PCS
G		Screw	8#*11/4	2 PCS
H		Plastic Anchor		2 PCS
I		Hanger	75*30*38mm 3mm	2 PCS
J		Connecting Plate	76*38*3mm	1 PC
K		Screw		2 PCS

PARTS LIST				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
1		Bookcase Hutch		1 PC
2		Open Shelf Cabinet		1 PC
3		50in Desktop		1 PC
4		Pedestal Leg		1 PC


HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
L		Allen Wrench	73*29*5mm	1 PC
M		Bolt	5/16*65mm	3 PCS
N		Bolt	1/4*19mm	6 PCS
O		Lock Washer	5/16	3 PCS
P		Flat Washer	5/16*22mm	3 PCS
Q		Lock Washer	1/4(6mm)	6 PCS
R		Flat Washer	1/4*16mm 1.5mm	6 PCS

HOOKER FURNISHINGS

ASSEMBLY INSTRUCTION

ITEM: 6820-10072-80 50in Desktop
6820-10072-85 50in Desktop
6820-10072-99 50in Desktop
6820-10413-80 Open Shelf Cabinet
6820-10413-85 Open Shelf Cabinet
6820-10413-99 Open Shelf Cabinet
6820-10417-80 Bookcase Hutch
6820-10417-85 Bookcase Hutch
6820-10417-99 Bookcase Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



Assembly steps for connecting Open Shelf Cabinet (2) and Bookcase Hutch (1):

Place Bookcase Hutch (1) on top of Open Shelf Cabinet (2),
then secure them with mending plates (B), bolts (C), lock washers (E), flat washers (F) and a Phillips screwdriver.


HOOKER FURNISHINGS

ASSEMBLY INSTRUCTION

ITEM: 6820-10072-80 50in Desktop
6820-10072-85 50in Desktop
6820-10072-99 50in Desktop
6820-10413-80 Open Shelf Cabinet
6820-10413-85 Open Shelf Cabinet
6820-10413-99 Open Shelf Cabinet
6820-10417-80 Bookcase Hutch
6820-10417-85 Bookcase Hutch
6820-10417-99 Bookcase Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

Screwdriver
(not provided)



If assembling multiple bookcase hutches, secure them together using Connecting plate (J) and Screw (K), then tighten with a Phillips screwdriver.

The adjustable shelves are screwed in place to avoid damage during transit.
To adjust the shelf height, remove screws then place shelf pins in the desired level.

HOOKER FURNISHINGS


ASSEMBLY INSTRUCTION

ITEM: 6820-10072-80 50in Desktop
6820-10072-85 50in Desktop
6820-10072-99 50in Desktop
6820-10413-80 Open Shelf Cabinet
6820-10413-85 Open Shelf Cabinet
6820-10413-99 Open Shelf Cabinet
6820-10417-80 Bookcase Hutch
6820-10417-85 Bookcase Hutch
6820-10417-99 Bookcase Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

Assembly steps for connecting 50in Desktop (3) and Pedestal Leg (4):

Secure them by using bolts (M), lock washers (O), flat washers (P) and Allen wrench (L).



HOOKER FURNISHINGS


ASSEMBLY INSTRUCTION

ITEM: 6820-10072-80 50in Desktop
6820-10072-85 50in Desktop
6820-10072-99 50in Desktop
6820-10413-80 Open Shelf Cabinet
6820-10413-85 Open Shelf Cabinet
6820-10413-99 Open Shelf Cabinet
6820-10417-80 Bookcase Hutch
6820-10417-85 Bookcase Hutch
6820-10417-99 Bookcase Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.

Assembly steps for connecting 50in Desktop (3) and Open Shelf Cabinet (2):

Secure them by using bolts (N), lock washers (Q), flat washers (R) and Allen wrench (A).




HOOKER FURNISHINGS

ASSEMBLY INSTRUCTION

ITEM: 6820-10072-80 50in Desktop
6820-10072-85 50in Desktop
6820-10072-99 50in Desktop
6820-10413-80 Open Shelf Cabinet
6820-10413-85 Open Shelf Cabinet
6820-10413-99 Open Shelf Cabinet
6820-10417-80 Bookcase Hutch
6820-10417-85 Bookcase Hutch
6820-10417-99 Bookcase Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



Adjust leveler if needed to level cabinet on uneven floor.