HOOKER® FURNISHINGS

ASSEMBLY INSTRUCTION


ITEM: (US16027M) SS757-PHZ25-004,SS757-PHZ25-088


Simone ZG 2 over 2 PWR Sofa w/PWR Headrest and BT speaker


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.


Read all instruction and study the drawing carefully before starting the assembly process.

PART LIST


NO .	DESCRIPTION	SKETCH	QTY
A	Seat		1PC
B	Left Back Cushion		1PC
C	Right Back Cushion		1PC
D	Power cord		1PC









STEP 1 - Connect the wire on back cushion and seat cushion



STEP 2 - place Bracket into Sleeve and press top of back down. firmly to lock your KD back in place



STEP 3 - Connect the connector from motor to the power cord and transformer.



STEP 4 -Use the hand controller to enjoy your Hooker Furnishing

CAUTION

Do not allow children to play on this mechanism furniture or operate the mechanism. Leg rest folds down on closing so that child could possibly be injured. Always leave in an upright and closed position and keep hands feet clear of mechanism. Only the occupant should operate it.

B0402

HOOKER® FURNISHINGS

ASSEMBLY INSTRUCTION

ITEM: (US16027M) SS757-PHZ25-004,SS757-PHZ25-088 Simone ZG 2 over 2 PWR Sofa w/PWR Headrest and BT speaker

Your Hooker furnishing seating experience goes beyond comfort, with built-in Bluetooth audio designed for effortless enjoyment.

Step 1: Power on


Connect the power to your seating.


- **Sectional:**

Ensure the section are powered and connected before moving to the next step.

- **Armchair:**

Once powered, you can move straight to Step 2.





You'll hear a voice prompt indicating the speaker is ready to connect.

Step 2: Connect Your Device
Open the Bluetooth settings on your phone or tablet and select "CNDoer" from the list of available devices.
A confirmation sound will let you know when pairing is complete.

Step 3: Press Play & Relax

Stream your favourite music, podcasts, or shows directly through your sofa
— no extra speakers, no clutter. Just effortless sound, built in.

Need a quick reset?
If the connection doesn't happen straight away, simply unplug the lounge,
then try reconnecting via your Bluetooth settings.
Sit back and enjoy sound that fits seamlessly into your lounge.

NOTES:

1)To help prevent shock and or damage to your product only plug the power cord into a grounded outlet.
2)Read the operating instructions carefully before operating your power sofa.