

ASSEMBLY INSTRUCTION

ITEM: 6820-10415-80 Three Drawer Chest
 6820-10415-85 Three Drawer Chest
 6820-10415-99 Three Drawer Chest
 6820-10417-80 Bookcase Hutch
 6820-10417-85 Bookcase Hutch
 6820-10417-99 Bookcase Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	69*27.2*4mm	1 PC
B		Mending Plate	100*25*2mm	2 PCS
C		Bolt	1/4"*20	4 PCS
D		Bolt	1/4*19mm	2 PCS
E		Lock Washer	1/4(6mm)	6 PCS
F		Flat Washer	1/4*16mm 1.5mm	6 PCS
G		Screw	8#*11/4	2 PCS
H		Plastic Anchor		2 PCS
I		Hanger	75*30*38mm 3mm	2 PCS
J		Connecting Plate	76*38*3mm	1 PC
K		Screw		4 PCS


PARTS LIST				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
1		Bookcase Hutch		1 PC
2		Three Drawer Chest		1 PC

ASSEMBLY INSTRUCTION

ITEM: 6820-10415-80 Three Drawer Chest
6820-10415-85 Three Drawer Chest
6820-10415-99 Three Drawer Chest
6820-10417-80 Bookcase Hutch
6820-10417-85 Bookcase Hutch
6820-10417-99 Bookcase Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.




ASSEMBLY INSTRUCTION

ITEM: 6820-10415-80 Three Drawer Chest
 6820-10415-85 Three Drawer Chest
 6820-10415-99 Three Drawer Chest
 6820-10417-80 Bookcase Hutch
 6820-10417-85 Bookcase Hutch
 6820-10417-99 Bookcase Hutch


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



Screwdriver
(not provided)

If assembling multiple bookcase hutches, secure them together using Connecting plate (J) and Screw (K), then tighten with a Phillips screwdriver.




The adjustable shelves are screwed in place to avoid damage during transit. To adjust the shelf height, remove screws then place shelf pins in the desired level.

ASSEMBLY INSTRUCTION

ITEM: 6820-10415-80 Three Drawer Chest
6820-10415-85 Three Drawer Chest
6820-10415-99 Three Drawer Chest
6820-10417-80 Bookcase Hutch
6820-10417-85 Bookcase Hutch
6820-10417-99 Bookcase Hutch

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



Adjust leveler if needed to level chest on uneven floor.