

# PALECEK®

601 PARR BOULEVARD | RICHMOND | CA 94801

## CHANDELIER INSTALLATION INSTRUCTIONS

### VICENTE CHANDELIER

239579



#### PROFESSIONAL INSTALLATION REQUIRED

**CAUTION: BEFORE INSTALLING FIXTURE, MAKE SURE THE POWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKER UTILITY BOX.**

#### Important Safety Instructions:

- These instructions are provided for your safety. Read carefully before use to ensure proper installation and operation.
- Installation by a licensed professional electrician is required.
- THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH APPLICABLE ELECTRICAL CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
- The fixture is intended for indoor use, dry locations only.
- It must be connected to a 3-wire, single-phase electrical system (with ground wire or equivalent protective conductor).
- For safety and convenience, installation by two people is strongly recommended.
- This fixture is rated for eight (8) 9.5-watt maximum T9 or T10 LED bulbs (not included) or eight (8) 60-watt maximum T9 or T10 incandescent bulbs (not included). A frosted T10 bulb, 11.8" in length overall is ideal.

⚠ To avoid fire hazard, do not exceed the recommended wattage.

- **Save these instructions for future reference.**

#### WARNING:

- **To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and allow it to cool prior to replacing light bulb.**
- **Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.**
- **Keep flammable materials away from lit bulb.**
- **Check the cable properly for any loose or damaged connections.**
- **When the unit is no longer functioning, do not attempt to fix it by yourself. Only a qualified technician is allowed to disassemble and repair.**
- **If the external flexible cable cord of this luminaire is damaged it shall be exclusively replaced by a qualified electrician in order to avoid hazard.**



## Installation Instructions:

1. **SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.**
2. Gently pull the existing wires down from the ceiling junction box and let them hang. Use a tape measure to decide your desired hanging height for the chandelier. Use the appropriate combination of downrods to create this hanging height.
3. Feed cord from Light fixture through Downrods, Hanger set (C), Canopy (H), Mounting plate (B). Attach the Downrods to Light fixture (D).
4. Secure the Mounting Plate (B) to the ceiling junction box with the Mounting Screws (G). Tighten until snug.
5. Fasten the ground wire from the fixture to the ceiling junction box and tight by Wire Nut (A) then wrap by electrical tape. **NEVER FASTEN THE GROUND WIRE TO THE BLACK OR "HOT" WIRE ! FAILURE TO FOLLOW THIS INSTRUCTION COULD RESULT IN SERIOUS INJURY OR DEATH !**

Fasten the Neutral wire (White wire) from the fixture to the ceiling junction box and tight by Wire Nut (A) then wrap by electrical tape. Fasten the Hot wire (Black wire) from the fixture to the ceiling junction box and tight by Wire Nut (A) then wrap by electrical tape. Make sure that there is no exposed wire or strands that could cause a dangerous short circuit !

6. After all connections are made gently tuck wire connections into the ceiling junction box.
7. Connect the Hanger set (C) to Downrod assembly by turning the Hanger into the thread on the top Downrod.
8. Attach the Hanger set (C) to the Mounting plate (B) by turning the Thread Ring on Hanger set (C) into the threaded nipple of the Mounting plate (B). Align hole of Canopy (H) to Nipple on Mounting plate (B) and secure it by turning the Screw collar on Hanger set (C) clockwise.
9. Insert eight (8) 9.5W max type T9 or T10 LED bulbs (not included) or eight (8) 60-watt max type T9 or T10 incandescent bulbs (not included) into the socket. A frosted T10 bulb, 11.8" in length overall is ideal for this fixture. Use only bulbs of the recommended type and wattage to avoid fire hazard.
10. Attach eight (8) the Glass Shades (F) to the Light Fixture (D) by turning it clockwise.
11. Restore power at the circuit breaker and test the fixture.

## Care Instructions:

- Do not use abrasive cleaning solution as it may cause damage to the fixture's finish.
- Wipe clean with a soft, dry cloth or static duster.